



REV 1.0

### SECURE CABIN

#### *SET FUEL & PAYLOAD*

BATTERY.....ON & COVERED  
 STANDBY PWR.....AUTO & COVERED  
 DC VOLTMETER SLCTR.....BAT  
 AC VOLTMETER SLCTR.....STBY PWR  
 MASTER CAUTION.....DISENGAGE  
 HYD PUMPS.....ALL OFF  
 FUEL PUMPS.....ALL OFF  
 GROUND POWER.....CONNECT & ON  
 INTERIOR LIGHTS.....AS REQUIRED

#### *FIRE & LIGHTS TESTS*

IRS SELECTORS (L & R).....NAV  
 IRS SEL.....TEST & HDG/STS

#### *OVERHEAD PANEL SCAN*

FUEL PUMP FWD NO.1.....ON  
 APU.....START  
 CAB/UTIL POWER.....ON  
 IFE PASS.....ON  
 GEN BUS TRNSFR SWITCH.....CHECK COVERED  
 EMERGENCY LIGHTS.....ARMED & COVERED  
 SEAT BELTS.....AUTO  
 APU GEN SWITCHES (L & R).....ON  
 WINDOW HEAT.....ON <10C  
 EXTEROR LIGHTS.....POSITION STEADY  
 RECIRC FANS (L & R).....AUTO  
 PACKS (L & R).....AUTO  
 ISOLATION VALVE.....AUTO  
 APU BLEED.....ON  
 FLIGHT ALT.....SET  
 LAND ALT.....SET  
 SPEEDBRAKE.....OFF  
 FLAPS.....OFF  
 AUTOPILOTS.....OFF  
 RADIO COMS.....AS REQUIRED

#### *ATC CLEARANCE*

#### *ENTER FMC AND COMPLETE*

SQUAK.....SET  
 ALTIMETER.....SET

FIRST ALT.....SET  
 PARKING BREAK.....SET  
 GROUND CONNECTIONS.....DSCNCT/RMVE ALL  
 MASTER CAUTION.....DISENGAGE  
*CHECK DOORS CLOSED*  
 FUEL PUMPS.....ALL (USABLE) ON  
 HYD PUMPS.....ALL ON  
 PACKS (L & R).....OFF  
 ANTI COLLISION LIGHTS.....ON  
 THRUST.....IDLE

### PUSHBACK AND START

#### *ATC PUSH & START*

PUSHBACK.....START  
*VERIFY DUCT PRESSURE GAUGE 30PSI*  
 R ENG STRT SWITCH.....GRD  
*WAIT FOR 25*  
 R ENG FUEL CTRL.....ON  
*WAIT FOR ENG START TO KICK BACK*  
 R ENG STRT SWITCH.....CONT  
 L ENG STRT SWITCH.....GRD  
*WAIT FOR 25*  
 L ENG FUEL CTRL.....ON  
*WAIT FOR ENG START TO KICK BACK*  
 L ENG STRT SWITCH.....CONT  
 ENG GEN SWITCHES (L & R).....ON  
 AC VOLTMETER SLCTR.....GEN1  
 PACKS (L & R).....AUTO  
 APU BLEED.....OFF  
 APU.....OFF  
 PITOT HEAT (PROBE).....ON  
 ANTI-ICE SWITCHES.....ON <10C  
 YAW DAMPER.....ON  
 FLAPS.....SET  
 AUTOBREAK (ANTISKID).....RTO  
 TAXI LIGHTS.....ON  
 RWY TURNOFF LIGHTS.....ON



REV 1.0

## TAXI

### ATC TAXI

- AP DISENGAGE BAR.....UP
- FLIGHT DIRECTORS (BOTH).....ON
- AUTO-THROTTLE.....ARM
- IAS.....V2
- HEADING.....RWY HDG
- ALTITUDE.....FIRST ALT

## HOLDING POINT

- LANDING LIGHTS.....ON
- RWY TURN OFF.....ON
- TAXI LIGHTS.....OFF
- POSITION LIGHTS.....STROBE & STEADY
- VNAV & LNAV.....ON
- TCAS.....TA/RA

## BEFORE TAKEOFF

- CLOCK.....START
- YOKE(+80KNOTS).....PUSH FORWARD
- VR.....ROTATE
- V2.....LIFT-OFF

## AFTER TAKEOFF

- POSITIVE RATE (500>FPM).....GEAR UP
- AUTOPilot (CMD).....ON
- FLAPS.....RAISE ON SCHEDULE
- AUTOBRAKE (ANTISKID).....OFF

## CLIMB

- LANDING LIGHTS.....OFF
- RWY TURNOFF LIGHTS.....OFF
- WHEEL WELL LIGHTS.....OFF
- ALTIMETER.....READJUST
- ANTI-ICE SWITCHES.....ON < 10C TAT

## CRUISE

### A/P & FMC MONITOR

- FMC PROGRS PAGE.....CHK FUEL CONSMPTN
- CENTER FUEL PUMP.....OFF (<450)

## DESCENT & APPROACH

### BEGIN PREP 30NM BEFORE T/D

- AUTOBREAKS.....SET
- COMPLETE FMC ARRIVAL PAGE
- ILS FREQ.....SET (NAV1 & NAV2)
- ILS CRS.....SET (BOTH)
- ALTIMETER.....READJSUT
- LANDING LIGHTS.....ON
- RWY TURNOFF LIGHTS.....ON
- SPOILERS.....AS REQUIRED

## FINAL APPROACH

- FLAPS.....LOWER ON SCHEDULE
- GEAR.....DOWN @ FLAPS 20
- AUTOPilot.....DISENGAGE
- AUTO-THROTTLE.....OFF
- SPOILERS.....ENGAGE
- THRUST RVRSR.....AS REQ (>80KNOTS)

## TAXI

- TRANSPOUNDER.....STDBY
- FLIGHT DIRECTORS.....OFF
- SPOILERS.....OFF
- FLAPS.....RETRACT
- AUTOBREAKS.....OFF
- TAXI LIGHTS.....ON
- LANDING LIGHTS.....OFF
- WHEEL WELL LIGHTS.....ON
- ANTI-ICE SWITCHES.....OFF
- APU.....START
- A/P.....RESET (BAR UP)



REV 1.0

## PARKING POSITION

PARKING BRAKE.....	SET
TAXI LIGHTS.....	OFF
APU GEN SWITCHES.....	ON
APU BLEED.....	ON
AC VOLTIMETER SLCTR.....	APU
ENG 1.....	CUT OFF
ENG 2.....	CUT OFF
MARTER WARNING.....	DISENGAGE
WHEEL CHOCKS.....	SET
PARKING BREAK.....	OFF
GROUND POWER.....	CONNECT & ON
DOORS.....	OPEN
SEAT BELTS.....	OFF
AC VOLTIMETER SLCTR.....	GND PWR
APU.....	OFF
APU BLEED.....	OFF
ANTI COLLITION LIGHTS.....	OFF
YAW DAMPER.....	OFF
PITOT HEAT (PROBE).....	OFF
ENG START SWITCHES.....	BOTH OFF
HYD PUMPS.....	ALL OFF
FUEL PUMPS.....	ALL OFF
MASTER WARNING.....	DISENGAGE
EXTERNAL LIGHTS.....	ALL OFF
EMERGENCY LIGHTS.....	OFF
IRS SELECTORS.....	BOTH OFF

INTERIOR LIGHTS.....	ALL OFF
DC VOLTIMETER SLCTR.....	STBY PWR
MASTER WARNING.....	DISENGAGE
STANDBY PWR.....	OFF & UNCOVERED
BATTERY.....	OFF & UNCOVERED

## SHUTDOWN

AC VOLTIMETER SLCTR.....	STBY PWR
GROUND POWER.....	OFF
GROUND POWER.....	DISCONNECT
BLEEDS.....	OFF
PACKS (L & R).....	OFF
ISOLATION VALVE.....	OFF
RECIRC. FANS (L & R) .....	OFF
IFE PASS SEAR POWER.....	OFF
CAB/UTIL POWER.....	OFF